



STEP 1

Remove the old filter by disconnecting the tubings from the quick connections.



STEP 1

Remove the old filter by disconnecting the tubings from the quick connections.



STEP 2

Insert the included quick connect T fitting into the inlet of the post carbon filter.



STEP 2

Insert the included quick connect T fitting into the inlet of the post carbon filter.



STEP 3

Insert the blue tubing directly into the outlet of the cartridge (or add an optional quick connect elbow fitting), and connect the yellow and white tubings to the T fitting.



STEP 3

Insert the blue tubing directly into the outlet of the cartridge (or add an optional quick connect elbow fitting), and connect the yellow and white tubings to the T fitting.



STEP 4

For 6 stage systems, connect the tubing from the outlet of the post carbon filter to the 6th stage.



STEP 4

For 6 stage systems, connect the tubing from the outlet of the post carbon filter to the 6th stage.